4900 Cartridge Installation / Door Stopper

Insert one supplied door stopper per door that will remain open. On a 4900 cartridges are inserted on both the left and the right side of the printer in designated slots.

Part: Door Stopper Do not throw away





After filling and installing the cartridges in the 4900 printer, insert door stopper(s).







Pull the Tab gently downwards in place as shown. Be careful not to stretch the stopper.



With the stopper in place the printer will read the door as closed.

